

Power Analyser
UMG 605-PRO
Installationsanleitung

Art. Nr. 35303-337
09/2020
Dok.-Nr. 203861919/b
www.janitza.de

1 Allgemeines

Haltungsauschluss
Die Beschaffung der Informationsprodukte zu den Geräten ist Voraussetzung für den sicheren Betrieb und um angegebene Leistungsmerkmale und Produkteigenschaften zu erreichen.

- Produktbegleitende Dokumente während der gesamten Lebensdauer verfügbar halten und gegebenenfalls an nachfolgende Benutzer weitergeben.
- Bitte informieren Sie uns über Geräteteile, die Sie nicht mit verbundenen Anpassungen der produktbegleitenden Dokumentation auf www.janitza.de.

Entsorgung
Bitte beachten Sie nationale Bestimmungen! Entsorgen Sie gegebenenfalls einzelne Teile, je nach Beschaffenheit und existierende länder-spezifische Normen, z.B. als:

- Elektroabfall
- Kunststoffe
- Metalle oder beauftragen Sie einen zertifizierten Entsorgungsgefecht mit der Verschrottung.

Relevante Gesetze,
angewandte Normen und Richtlinien:
Die von der Janitza electronics GmbH ange-wandten Gesetze, Normen und Richtlinien für das Gerät nehmen Sie der Konformitäts-klärung auf unserer Website (www.janitza.de).

Technische Anerkennungen vorbehaltlich:

- Achten Sie darauf, dass Ihr Gerät mit der Installationsanleitung übereinstimmt.
- Lesen und verstehen Sie zunächst produktbegleitende Dokumente.

Sicherheitshinweise

Gefahr
Weist auf eine unmittelbar drohende Gefahr hin, die zu schweren bzw. tödlichen Verletzungen führt.

GEFAHR
Weist auf eine möglicherweise gefährliche Situation hin, die zu schweren Verletzungen oder Tod führen kann.

WANDELN!
Weist auf eine möglicherweise gefährliche Situation hin, die zu leichten Verletzungen oder Sachschäden führen kann.

VORSICHT!
Weist auf eine möglicherweise gefährliche Situation hin, die zu leichteren Verletzungen oder Sachschäden führen kann.

Sicherheitsmaßnahmen

Durch Nichtbeachtung der Anschlussbedingungen für die Spannungsmessung können gefährliche Spannungen im Gerät vorhanden sein (Kontaktpfeiler).

Bestreiter Sicherheitsmaßnahmen können weitere Schäden verursachen. Dies ist insbesondere bei der Inbetriebnahme des Geräts der Fall.

Qualifiziertes Personal
Um Personen- und Sachschäden zu vermeiden, darf nur qualifiziertes Personal mit elektrotechnischer Ausbildung am Gerät arbeiten mit Kenntnissen:


- DIN EN 60068-2-27
- DIN EN 60068-2-29
- DIN EN 60068-2-32
- DIN EN 60068-2-33
- DIN EN 60068-2-34
- DIN EN 60068-2-35
- DIN EN 60068-2-36
- DIN EN 60068-2-37
- DIN EN 60068-2-38
- DIN EN 60068-2-39
- DIN EN 60068-2-40
- DIN EN 60068-2-41
- DIN EN 60068-2-42
- DIN EN 60068-2-43
- DIN EN 60068-2-44
- DIN EN 60068-2-45
- DIN EN 60068-2-46
- DIN EN 60068-2-47
- DIN EN 60068-2-48
- DIN EN 60068-2-49
- DIN EN 60068-2-50
- DIN EN 60068-2-51
- DIN EN 60068-2-52
- DIN EN 60068-2-53
- DIN EN 60068-2-54
- DIN EN 60068-2-55
- DIN EN 60068-2-56
- DIN EN 60068-2-57
- DIN EN 60068-2-58
- DIN EN 60068-2-59
- DIN EN 60068-2-60
- DIN EN 60068-2-61
- DIN EN 60068-2-62
- DIN EN 60068-2-63
- DIN EN 60068-2-64
- DIN EN 60068-2-65
- DIN EN 60068-2-66
- DIN EN 60068-2-67
- DIN EN 60068-2-68
- DIN EN 60068-2-69
- DIN EN 60068-2-70
- DIN EN 60068-2-71
- DIN EN 60068-2-72
- DIN EN 60068-2-73
- DIN EN 60068-2-74
- DIN EN 60068-2-75
- DIN EN 60068-2-76
- DIN EN 60068-2-77
- DIN EN 60068-2-78
- DIN EN 60068-2-79
- DIN EN 60068-2-80
- DIN EN 60068-2-81
- DIN EN 60068-2-82
- DIN EN 60068-2-83
- DIN EN 60068-2-84
- DIN EN 60068-2-85
- DIN EN 60068-2-86
- DIN EN 60068-2-87
- DIN EN 60068-2-88
- DIN EN 60068-2-89
- DIN EN 60068-2-90
- DIN EN 60068-2-91
- DIN EN 60068-2-92
- DIN EN 60068-2-93
- DIN EN 60068-2-94
- DIN EN 60068-2-95
- DIN EN 60068-2-96
- DIN EN 60068-2-97
- DIN EN 60068-2-98
- DIN EN 60068-2-99
- DIN EN 60068-2-100
- DIN EN 60068-2-101
- DIN EN 60068-2-102
- DIN EN 60068-2-103
- DIN EN 60068-2-104
- DIN EN 60068-2-105
- DIN EN 60068-2-106
- DIN EN 60068-2-107
- DIN EN 60068-2-108
- DIN EN 60068-2-109
- DIN EN 60068-2-110
- DIN EN 60068-2-111
- DIN EN 60068-2-112
- DIN EN 60068-2-113
- DIN EN 60068-2-114
- DIN EN 60068-2-115
- DIN EN 60068-2-116
- DIN EN 60068-2-117
- DIN EN 60068-2-118
- DIN EN 60068-2-119
- DIN EN 60068-2-120
- DIN EN 60068-2-121
- DIN EN 60068-2-122
- DIN EN 60068-2-123
- DIN EN 60068-2-124
- DIN EN 60068-2-125
- DIN EN 60068-2-126
- DIN EN 60068-2-127
- DIN EN 60068-2-128
- DIN EN 60068-2-129
- DIN EN 60068-2-130
- DIN EN 60068-2-131
- DIN EN 60068-2-132
- DIN EN 60068-2-133
- DIN EN 60068-2-134
- DIN EN 60068-2-135
- DIN EN 60068-2-136
- DIN EN 60068-2-137
- DIN EN 60068-2-138
- DIN EN 60068-2-139
- DIN EN 60068-2-140
- DIN EN 60068-2-141
- DIN EN 60068-2-142
- DIN EN 60068-2-143
- DIN EN 60068-2-144
- DIN EN 60068-2-145
- DIN EN 60068-2-146
- DIN EN 60068-2-147
- DIN EN 60068-2-148
- DIN EN 60068-2-149
- DIN EN 60068-2-150
- DIN EN 60068-2-151
- DIN EN 60068-2-152
- DIN EN 60068-2-153
- DIN EN 60068-2-154
- DIN EN 60068-2-155
- DIN EN 60068-2-156
- DIN EN 60068-2-157
- DIN EN 60068-2-158
- DIN EN 60068-2-159
- DIN EN 60068-2-160
- DIN EN 60068-2-161
- DIN EN 60068-2-162
- DIN EN 60068-2-163
- DIN EN 60068-2-164
- DIN EN 60068-2-165
- DIN EN 60068-2-166
- DIN EN 60068-2-167
- DIN EN 60068-2-168
- DIN EN 60068-2-169
- DIN EN 60068-2-170
- DIN EN 60068-2-171
- DIN EN 60068-2-172
- DIN EN 60068-2-173
- DIN EN 60068-2-174
- DIN EN 60068-2-175
- DIN EN 60068-2-176
- DIN EN 60068-2-177
- DIN EN 60068-2-178
- DIN EN 60068-2-179
- DIN EN 60068-2-180
- DIN EN 60068-2-181
- DIN EN 60068-2-182
- DIN EN 60068-2-183
- DIN EN 60068-2-184
- DIN EN 60068-2-185
- DIN EN 60068-2-186
- DIN EN 60068-2-187
- DIN EN 60068-2-188
- DIN EN 60068-2-189
- DIN EN 60068-2-190
- DIN EN 60068-2-191
- DIN EN 60068-2-192
- DIN EN 60068-2-193
- DIN EN 60068-2-194
- DIN EN 60068-2-195
- DIN EN 60068-2-196
- DIN EN 60068-2-197
- DIN EN 60068-2-198
- DIN EN 60068-2-199
- DIN EN 60068-2-200
- DIN EN 60068-2-201
- DIN EN 60068-2-202
- DIN EN 60068-2-203
- DIN EN 60068-2-204
- DIN EN 60068-2-205
- DIN EN 60068-2-206
- DIN EN 60068-2-207
- DIN EN 60068-2-208
- DIN EN 60068-2-209
- DIN EN 60068-2-210
- DIN EN 60068-2-211
- DIN EN 60068-2-212
- DIN EN 60068-2-213
- DIN EN 60068-2-214
- DIN EN 60068-2-215
- DIN EN 60068-2-216
- DIN EN 60068-2-217
- DIN EN 60068-2-218
- DIN EN 60068-2-219
- DIN EN 60068-2-220
- DIN EN 60068-2-221
- DIN EN 60068-2-222
- DIN EN 60068-2-223
- DIN EN 60068-2-224
- DIN EN 60068-2-225
- DIN EN 60068-2-226
- DIN EN 60068-2-227
- DIN EN 60068-2-228
- DIN EN 60068-2-229
- DIN EN 60068-2-230
- DIN EN 60068-2-231
- DIN EN 60068-2-232
- DIN EN 60068-2-233
- DIN EN 60068-2-234
- DIN EN 60068-2-235
- DIN EN 60068-2-236
- DIN EN 60068-2-237
- DIN EN 60068-2-238
- DIN EN 60068-2-239
- DIN EN 60068-2-240
- DIN EN 60068-2-241
- DIN EN 60068-2-242
- DIN EN 60068-2-243
- DIN EN 60068-2-244
- DIN EN 60068-2-245
- DIN EN 60068-2-246
- DIN EN 60068-2-247
- DIN EN 60068-2-248
- DIN EN 60068-2-249
- DIN EN 60068-2-250
- DIN EN 60068-2-251
- DIN EN 60068-2-252
- DIN EN 60068-2-253
- DIN EN 60068-2-254
- DIN EN 60068-2-255
- DIN EN 60068-2-256
- DIN EN 60068-2-257
- DIN EN 60068-2-258
- DIN EN 60068-2-259
- DIN EN 60068-2-260
- DIN EN 60068-2-261
- DIN EN 60068-2-262
- DIN EN 60068-2-263
- DIN EN 60068-2-264
- DIN EN 60068-2-265
- DIN EN 60068-2-266
- DIN EN 60068-2-267
- DIN EN 60068-2-268
- DIN EN 60068-2-269
- DIN EN 60068-2-270
- DIN EN 60068-2-271
- DIN EN 60068-2-272
- DIN EN 60068-2-273
- DIN EN 60068-2-274
- DIN EN 60068-2-275
- DIN EN 60068-2-276
- DIN EN 60068-2-277
- DIN EN 60068-2-278
- DIN EN 60068-2-279
- DIN EN 60068-2-280
- DIN EN 60068-2-281
- DIN EN 60068-2-282
- DIN EN 60068-2-283
- DIN EN 60068-2-284
- DIN EN 60068-2-285
- DIN EN 60068-2-286
- DIN EN 60068-2-287
- DIN EN 60068-2-288
- DIN EN 60068-2-289
- DIN EN 60068-2-290
- DIN EN 60068-2-291
- DIN EN 60068-2-292
- DIN EN 60068-2-293
- DIN EN 60068-2-294
- DIN EN 60068-2-295
- DIN EN 60068-2-296
- DIN EN 60068-2-297
- DIN EN 60068-2-298
- DIN EN 60068-2-299
- DIN EN 60068-2-300
- DIN EN 60068-2-301
- DIN EN 60068-2-302
- DIN EN 60068-2-303
- DIN EN 60068-2-304
- DIN EN 60068-2-305
- DIN EN 60068-2-306
- DIN EN 60068-2-307
- DIN EN 60068-2-308
- DIN EN 60068-2-309
- DIN EN 60068-2-310
- DIN EN 60068-2-311
- DIN EN 60068-2-312
- DIN EN 60068-2-313
- DIN EN 60068-2-314
- DIN EN 60068-2-315
- DIN EN 60068-2-316
- DIN EN 60068-2-317
- DIN EN 60068-2-318
- DIN EN 60068-2-319
- DIN EN 60068-2-320
- DIN EN 60068-2-321
- DIN EN 60068-2-322
- DIN EN 60068-2-323
- DIN EN 60068-2-324
- DIN EN 60068-2-325
- DIN EN 60068-2-326
- DIN EN 60068-2-327
- DIN EN 60068-2-328
- DIN EN 60068-2-329
- DIN EN 60068-2-330
- DIN EN 60068-2-331
- DIN EN 60068-2-332
- DIN EN 60068-2-333
- DIN EN 60068-2-334
- DIN EN 60068-2-335
- DIN EN 60068-2-336
- DIN EN 60068-2-337
- DIN EN 60068-2-338
- DIN EN 60068-2-339
- DIN EN 60068-2-340
- DIN EN 60068-2-341
- DIN EN 60068-2-342
- DIN EN 60068-2-343
- DIN EN 60068-2-344
- DIN EN 60068-2-345
- DIN EN 60068-2-346
- DIN EN 60068-2-347
- DIN EN 60068-2-348
- DIN EN 60068-2-349
- DIN EN 60068-2-350
- DIN EN 60068-2-351
- DIN EN 60068-2-352
- DIN EN 60068-2-353
- DIN EN 60068-2-354
- DIN EN 60068-2-355
- DIN EN 60068-2-356
- DIN EN 60068-2-357
- DIN EN 60068-2-358
- DIN EN 60068-2-359
- DIN EN 60068-2-360
- DIN EN 60068-2-361
- DIN EN 60068-2-362
- DIN EN 60068-2-363
- DIN EN 60068-2-364
- DIN EN 60068-2-365
- DIN EN 60068-2-366
- DIN EN 60068-2-367
- DIN EN 60068-2-368
- DIN EN 60068-2-369
- DIN EN 60068-2-370
- DIN EN 60068-2-371
- DIN EN 60068-2-372
- DIN EN 60068-2-373
- DIN EN 60068-2-



Janitza electronics GmbH
Vor den Polstücken 6
D-55633 Lahnau / Germany
Support tel. +49 6441 9642-22
e-mail: info@janitza.com
www.janitza.com

Janitza®

Suitable network systems and maximum rated voltages (DIN EN 61010-1/A1):




The device can be used in:
• 2-, 3- and 4-conductor networks (TN, TT and IT networks)
• domestic and industrial settings

NOTE!

As an alternative to the fuse and circuit breaker, you can use a line safety switch.

5 Network systems

The device only determines measured values if measured voltage of >10 Veff is present on at least one voltage measurement input.




The device can be used in:
• 2-, 3- and 4-conductor networks (TN, TT and IT networks)

NOTE!

The measurement and surge voltages meet overvoltage category 300 V CAT III.

6 Voltage measurement

The device only determines measured values if measured voltage of >10 Veff is present on at least one voltage measurement input.




The device can be used in:
• 2-, 3- and 4-conductor networks (TN, TT and IT networks)

NOTE!

The measurement and surge voltages meet overvoltage category 300 V CAT III.

7 Current measurement

The device is only approved for measuring current with a current transformer.



The device can be used in:
• must not be occupied with DC voltage.
• must be provided with a suitable, labelled fuse that is positioned close by and is easily accessible (alternatively: a line safety switch)

NOTE!

Severe bodily injury or death can occur due to:
• touching bare or stripped wires that are live.
• current measurement inputs that are dangerous to touch on the device and on the current transformers.
• dangerous to touch.
• Voltages that exceed the permissible network rated voltages must be connected via a line safety switch.
• Measured voltages and currents must derive from the same network.

NOTE!

Risk of injury due to electric voltage!

WARNING!

Severe bodily injury or death can occur due to:
• touching bare or stripped wires that are live.
• current measurement inputs that are dangerous to touch on the device and on the current transformers.
• dangerous to touch.
• Voltages that exceed the permissible network rated voltages must be connected via a line safety switch.
• Measured voltages and currents must derive from the same network.

NOTE!

Risk of injury due to large currents and high electric voltages!

WARNING!


Severe bodily injury or death can occur due to:
• touching bare or stripped wires that are live.
• current measurement inputs that are dangerous to touch on the device and on the current transformers.
• dangerous to touch.
• Voltages that exceed the permissible network rated voltages must be connected via a line safety switch.
• Measured voltages and currents must derive from the same network.

NOTE!

Avoid open operation of the current transformers - short-circuit unloaded transformers!

8 Baseline measurement, inputs 1-3

Setting range on the device: Address 110 (see step 13)



Three-phase four-conductor system

Address 110 - Set: 0000

Measurement in the three-phase four-conductor system with asymmetric loading.

Address 110 - Set: 0004

Measurement in the three-phase four-conductor system with symmetric loading.

Address 110 - Set: 0008


Measurement in the three-phase three-conductor system with asymmetric loading.

Address 110 - Set: 0009

Measurement in the three-phase three-conductor system with symmetric loading.

9 Establish an Ethernet connection

The 3 most common connections for communication between PC and device:



The PC and the UMG 605-PRO require a static IP address.

The PC and the UMG 605-PRO require a static IP address.

The DHCP server assigns IP addresses to the UMG 605-PRO and the PC automatically.

NOTE!

Damage to property due to incorrect network settings


CAUTION!

Incorrect network settings can cause faults in the IT network.

Obtain information from your network administrator about the correct Ethernet network settings for your device.

10 Operation and button functions

The device is operated using buttons 1 and 2. The service button is designated for use by trained service employees only.



The device differentiates between display and programming mode (see step 11).

Button intervals:

• Press the appropriate button for a short time:
• Scroll forwards.
• Digit value +1.

Press the appropriate button for a long time:
• Scroll backwards.
• Digit value -1.

To switch between display mode and programming mode, press and hold both buttons simultaneously for 1 second.

The device switches from programming mode to display mode if:
• no buttons are pressed for 60 seconds.
• buttons 1 and 2 are pressed simultaneously for 1 second.

NOTE!


Changes are only applied after exiting programming mode.

NOTE!

For further information on button functions and parameter settings, see the user manual.

11 Display mode

After the power return, the device is in display mode. In display mode, the device is in programming mode.



The most important settings on the device are carried out in programming mode (PRG).

Use device addresses 002 and 003 to configure the voltage transformer ratio for the baseline measurement.

The factory setting for the voltage transformer ratio for all voltage transformer inputs (baseline and supporting) is 400 V/400 V (direct measurement).

NOTE!

Use device addresses 000 and 001 to configure the current transformer ratio for the baseline measurement.

The factory setting for the current transformer ratio for all current transformer inputs (baseline and supporting) is 3 A/5 A.

NOTE!

Use device addresses 1-4 to scroll between the measured values for current, voltage, power, etc.

NOTE!

When you press and hold buttons 1 and 2 simultaneously for a long time, the device switches to programming mode as soon as no display password has been configured:


• The text "PRG" is shown on the display.
• The first digit in the address flashes.

NOTE!

You can make further settings in the GridVis® software.

12 Configuration of the voltage and current transformer ratio

Use device addresses 002 and 003 to configure the voltage transformer ratio for the baseline measurement.



The factory setting for the voltage transformer ratio for all voltage transformer inputs (baseline and supporting) is 400 V/400 V (direct measurement).

NOTE!

Use device addresses 000 and 001 to configure the current transformer ratio for the baseline measurement.

The factory setting for the current transformer ratio for all current transformer inputs (baseline and supporting) is 3 A/5 A.

NOTE!

Parameter list except of "voltage transformer values"

Parameter list except of "current transformer values"

NOTE!


For further information on measured value indications and the factory setting, see the user manual.

NOTE!

For further information on button functions and diagrams on supporting measurement, see the device's user manual.

13 Device settings for measurements

Device settings for "baseline measurement"



Device settings for "baseline measurement"

Device settings for "supporting measurement"

Device settings for "supporting measurement"

NOTE!


If the measurement range is exceeded, the measurement display shows "OVER".

For further information on the baseline measurement, see the user manual.

A supporting measurement via input L4 is configured with address 111 on the device. For settings, diagrams and information on supporting measurement, see the user manual.

14 Configure the Ethernet connection

Static IP address (Addr: 205, content = 0)



In networks without a DHCP server, select the network address (see table) on the device.

BootP (Addr: 205, content = 1)

BootP enables a UMG 605-PRO to be integrated into an existing network fully automatically. However, BootP is an older protocol and does not provide the scope of functions provided by DHCP.

DHCP client (Addr: 205, content = 2)

DHCP makes it possible to integrate a UMG 605-PRO into an existing network automatically without the need for any additional configuration.

When started, the UMG automatically obtains the IP address, the subnet mask and the gateway from the DHCP server. The default setting for the UMG 605-PRO is "DHCP client".

Zeroconf (Addr: 205, content = 3)


Setting to configure the UMG 605-PRO using the GridVis® software.

NOTE!

Further technical data can be found in the user manual for the device.

15 Configuring the device as a "DHCP client" or with a "Static IP address"

To configure the device as a "DHCP client" or with a "Static IP address", first set address 205 (DHCP mode).



1. Switch to programming mode as described (the first digit flashes).

2. Use button 2 to select value 2, "DHCP client" (the second digit flashes).

3. Press button 1 to confirm your entry.

The address display flashes.

NOTE!

Information on the settings can be found in the table in step 14.

Setting a "Static IP address"

1. Use button 2 to select value 0.

2. Press button 1 to confirm your entry.

The address display flashes.

NOTE!

Information on the settings can be found in the table in step 14.


Then select the "DHCP client" or the "Static IP address" in DHCP mode as follows:

NOTE!

Ensure that address 204 (RS232 mode) has the value 0 (default setting) to operate the device in DHCP client mode!

16 Configuring the "Static IP address"

If the device is accessed via a "Static IP address", the device requires settings for this:



1. Device IP address.

2. Subnet mask.

3. Gateway address (not required for configuration).

(see the table in step 14)

1. Setting the device IP address

(see step 15)