

# Getac

## Using the T800 Second Battery Pack

### Charging the Battery Pack

This second battery pack is a snap-on module to provide T800 with extra battery power.

To charge the battery pack, connect the AC adapter. The Battery Charge Indicator (BCI) glows amber to indicate that charging is in progress. It takes approximately 3 hours to fully charge the battery pack. When the battery is fully charged, the indicator glows green.




#### NOTE:

- For proper operation, make sure T800 is **NOT** connected to AC power whenever you try to attach or detach the second battery pack.
- After you attach the second battery pack and connect AC power to T800, the main battery will be charged first and then the second battery.

### Connecting the Battery Pack

1. Align the module with the back of T800, engage the module's bottom tab first and then snap the top tab into place.

2. Firmly press the connector area to ensure the connection. The module has an icon  indicating where to press.
3. Tighten four screws.




4. When connected, the second battery will be discharged first and then the main battery.

## Checking the Battery Level

**NOTE:** If the operating system does not seem to recognize the second battery pack, try disconnecting and reconnecting it.

After connection, the operating system's battery meter should show the second battery information.

The battery pack itself has an LED indicator for displaying the estimated battery charge. You can press the  button to see the number of segments that light green. Each segment represents approximately 20% charge.

